



MEG BRAFF DESIGNS

WALLPAPER HANGING INSTRUCTIONS

Please carefully inspect all wallcovering for possible defects. If the wallcovering is found to be defective in any way, **do not hang**. We will replace or issue credit for any defective rollage but we cannot be held responsible for any wallpaper hanging labor charges or claims.

WALL PREPARATION:

Remove any old wallcovering. Wall surfaces must be washed clean of all old paste. Imperfections in the wall surface should be removed and/or spackled. New plaster must be completely dry. Remove any sheen or gloss from wall surfaces with sandpaper. Wall areas of strong color contrast must be made uniform in color before the installation of any wallcovering. To prevent mildew from occurring, a wash with a strong household bleach will kill the bacteria from previous coverings. Rinse thoroughly with clear water.

We strongly recommend that prior to the hanging of any wallcovering, all walls are properly primed. Please see our recommended steps and products below:

1. Use the Benjamin Moore Fresh Start oil based primer. On new construction, spot prime repairs
2. Then, use the Shieldz wallpaper primer. Do not add water

ADHESIVE & HANGING TECHNIQUES:

We recommend using Dynamite Clear paste, with a paste-to-paper application. Please allow for a 1 to 3 minute booking time before applying the paper to the wall. For the edges, you may apply a light coat of paste on the wall where the seam will be.

Care should be taken to wash all excess adhesive from the surface of all wallcovering. Wash each strip thoroughly with clear water and a clean, soft sponge. Change rinse water often. Any adhesive that is left on the surface of the wallcovering can at a later date attack and damage the surface printed inks, and cause them to flake.

All Meg Braff Designs Wallpapers are non-woven, untrimmed, and screen-printed in the USA with vinyl based paints.

www.megbraffdesigns.com

NY (516) 801-4939 | FL (561) 508-4848 | info@megbraffdesigns.com